

MODELS D and DL

PRESSURE REDUCING REGULATORS

SECTION I

I. DESCRIPTION AND SCOPE

The Model D is a pressure reducing regulator used to control downstream (outlet or P_2) pressure. Sizes are 3/8" (DN10), 1/2" (DN15), 3/4" (DN20) and 1" (DN25). With proper trim utilization, the unit is suitable for liquid, gaseous, or steam service. Refer to Technical Bulletin D-TB for design conditions and selection recommendations.

The Model DL is also a pressure reducing regulator similar to above Model D. Sizes are 1-1/2" (DN40) and 2" (DN50). (Model DL was formerly a Cashco Model D). Refer to Technical Bulletin DL-TB for design conditions and selection recommendations.

SECTION II

II. INSTALLATION



CAUTION


For welded installations, all internal trim parts, seals and diaphragm(s) must be removed from regulator body prior to welding into pipeline. The heat of fusion welding will damage non-metallic parts if not removed. NOTE: This does not apply to units equipped with extended pipe nipples.

1. An inlet block valve should always be installed.
2. If service application is continuous such that shutdown is not readily accomplished, it is recommended that an inlet block valve, outlet block valve, and a manual bypass valve be installed.
3. Pipe unions should be installed to allow removal from piping, if flanges are not being used.
4. An outlet pressure gauge should be located approximately ten pipe diameters downstream and within sight.
5. All installations should include a downstream relief device if the inlet pressure could exceed the pressure rating of any downstream equipment or the maximum outlet pressure rating of the unit.



CAUTION

Installation of adequate overpressure protection is recommended to protect the regulator from overpressure and all downstream equipment from damage in the event of regulator failure.



**Recommended Piping Schematic
For Pressure Reducing Station**

6. Clean the piping of all foreign material including chips, welding scale, oil, grease and dirt before installing the regulator. Strainers are recommended.
7. If placing thread sealant on pipe ends prior to engagement, ensure that excess material is removed and not allowed to enter the regulator upon startup.
8. Flow Direction: Install so the flow direction matches the arrow on the body.
9. For best performance, install in well drained horizontal pipe, properly trapped, if a steam service application.
- 10.A. Basic Regulator - (Refer to Figure 2): Regulator may be rotated around the pipe axis 360°. Recommended position is with spring chamber vertical upwards. Orient such that the spring chamber vent hole does not collect rainwater or debris.



CAUTION

DO NOT HYDROSTATIC TEST THROUGH AN INSTALLED UNIT; ISOLATE REGULATOR FROM TEST. The upper range spring pressure level listed on the nameplate or 100 psig (6.9 Barg) minimum is the recommended “upper operative limit” for the sensing diaphragm (see Section IV. Startup, Number 7.) Higher pressures could cause internal damage. In addition, note on the nameplate that the Inlet and Outlet pressure and temperature ratings are at different levels.

10.B. Model D Cryogenic Regulator - Option D-5 or D-36

- a. Recommended installation is with spring chamber hanging directly below the body in a vertical downwards orientation. Allows water to drain; i.e. condensation.
 - b. Recommend inert purge gas to spring chamber through vent hole and out drain hole.
11. Regulators are not to be directly buried underground.
 12. For insulated piping systems, recommendation is to not insulate regulator.
 13. Spring Chamber Vent Tap - Pipe spring chamber vent opening to remote location. Orient so as not to take on rainwater.

SECTION III

III. PRINCIPLE OF OPERATION

1. Movement occurs as pressure variations register on the diaphragm. The registering pressure is the outlet, P_2 , or downstream pressure. The range spring or loading pressure (Opt.-20) opposes diaphragm movement. As outlet pressure drops, the range spring or loading pressure pushes

the diaphragm down, opening the port; as outlet pressure increases, the diaphragm pushes up and the port opening closes.

2. A complete diaphragm failure will cause the regulator to fail open.

SECTION IV

IV. STARTUP

1. Start with the block valves closed. A bypass valve may be used to maintain outlet pressure in the downstream system without changing the following steps.
2. Relax the range spring by turning the adjusting screw counter clockwise (CCW) a minimum of three (3) full revolutions or reduce loading pressure (Opt.-20). This reduces the outlet (downstream) pressure set point.
3. If it is a “hot” piping system, and equipped with a bypass valve, slowly open the bypass valve to pre-heat the system piping and to allow slow expansion of the piping. Ensure proper steam trap operation if installed. Closely monitor outlet (downstream) pressure via gauge to ensure not over-pressurizing.
NOTE: *If no bypass valve is installed, extra caution should be used in starting up a cold system; i.e. do everything slowly.*
4. Crack open the outlet (downstream) block valve.
5. Slowly open the inlet (upstream) block valve observing the outlet (downstream) pressure gauge. Determine if the regulator is flowing. If not, slowly rotate the regulator adjusting screw (6) clockwise (CW) or increase loading pressure (Opt.-20) until flow begins.

6. Continue to slowly open the inlet (upstream) block valve until fully open.
7. Continue to slowly open the outlet (downstream) block valve, especially when the downstream piping system isn't pressurized. If the outlet (downstream) pressure exceeds the desired pressure, close the inlet (upstream) block valve and go to Step 2, then return to Step 4.
8. When flow is established steady enough that the outlet (downstream) block valve is fully open, begin to slowly close the bypass valve if installed.
9. Develop system flow to a level near its expected normal rate, and reset the regulator set point by turning the adjusting screw (6) CW to increase outlet pressure, or CCW to reduce outlet pressure.
10. Reduce system flow to a minimum level and observe set point. Outlet pressure will rise from the set point of Step 9. The maximum rise in outlet pressure on decreasing flow should not exceed the stated upper limit of the range spring by greater than 10%; i.e. 10-40 psig (.69 - 2.8 Barg) range spring, at low flow the outlet pressure should not exceed 44 psig (3 Barg), if it does, consult factory.

SECTION V

V. SHUTDOWN

1. On systems with a bypass valve, and where system pressure is to be maintained as the regulator is shut down, slowly open the bypass valve while reducing spring tension or loading pressure (Opt.-20) and slowly closing the inlet (upstream) block valve. When all loading pressure is relieved, fully close the inlet (upstream) block valve. (When on bypass, the system pressure must be constantly observed and manually regulated.) Close the outlet (downstream) block valve.



CAUTION

Do not walk away and leave a bypassed regulator unattended!

2. If the regulator and system are to both be shutdown, remove all spring tension or loading pressure while slowly closing the inlet (upstream) block valve. Close the outlet (downstream) valve only if regulator removal is required.

SECTION VI

VI. MAINTENANCE

A. General:



WARNING

SYSTEM UNDER PRESSURE. Prior to performing any maintenance, isolate the regulator from the system and relieve all pressure. Failure to do so could result in personal injury.

1. Maintenance procedures hereinafter are based upon removal of the regulator unit from the pipeline where installed.
2. Owner should refer to owner's procedures for removal, handling, cleaning and disposal of nonreusable parts, i.e. gaskets, etc.
3. Refer to Figure 2 for basic regulator. For blow-ups of Option-4 Stabilizer, refer to Figure 1.

B. Diaphragm Replacement:

1. Securely install the body (1) in a vise with the spring chamber (2) loading chamber (33) directed upwards.



WARNING

SPRING UNDER COMPRESSION. Prior to removing flange bolts, relieve spring compression by backing out the adjusting screw. Failure to do so may result in flying parts that could cause personal injury.

2. Relax range spring (14) by turning adjusting screw (6) CCW until removed from spring chamber (2). **NOTE:** If the D-3 Option handwheel is utilized, the adjusting screw and locknut (7) are replaced respectively by handwheel adjusting screw (20) and locking lever (21). Refer to Figure 6.
3. Draw or embed a match mark between body (1) and spring chamber (2) or loading chamber (33) along flanged area.

4. Remove all diaphragm bolts (8), washers (26), and lock washers (25).
5. Remove spring chamber (2), (loading chamber 33), range spring (14), spring button (4), pressure plate (3), diaphragm(s) (12), and diaphragm gasket (13) for metal diaphragm. **NOTE:** Refer to the quantity of diaphragms (12) incorporated per the bill of materials listing. Depending on outlet pressure level, multiple metal diaphragms may be "stacked".
6. Remove pusher plate (11) and inspect for a fit which limits its travel to a vertical direction. Wear will show as excessive wobble in pusher plate. If apparent, recommend trim removal and inspection; go to Sub-Section C following. Reinstall pusher plate.
7. Inspect pressure plate (3) to ensure no deformation due to over-pressurization. If deformed, replace.
8. Clean body (1) and spring chamber (2) flanges. **NOTE:** On regulators originally supplied as "oxygen clean", Option D-5, D-36, D-55, or DL-55, maintenance must include a level of cleanliness equal to Cashco cleaning standard #S-1134. On regulators originally supplied as "cleaned for Pharmaceutical and Food applications" Option D-37 or D-37S, maintenance must include a level of cleanliness equal to Cashco cleaning standard #S-1576.
9. Place diaphragm gasket (13) on body (1) flange, if included. Position diaphragm(s) (12) into place. Visually center pressure plate (3) onto diaphragm(s), **NOTE:** No diaphragm gasket (13) for composition diaphragm.
10. Set range spring (14) onto retainer hub of pressure plate (3). Place multi-purpose, high temperature grease into depression of spring button (4) where adjusting screw (6) bears. Set spring button onto top of range spring; ensure spring button is laying flat.

11. Aligning the matchmarks, place spring chamber (2) over the above stacked parts. Install all bolts (8), washers (26), and lock washers (25), by hand. Mechanically tighten bolting in a cross pattern that allows spring chamber to be pulled down evenly. Recommended torque values are as follows:

NOTE: Never replace bolting (8) with just any bolting if lost. Bolt heads are marked with specification identification markings. Use only proper grades as replacements.

Model	Regulator Size	Bolt Size	Metal & Comp. Diaphragm
D	3/8" thru 1" (DN10 thru 25)	3/8"-24	20-24 Ft-Lbs (27-32 N-m)
DL	1-1/2" thru 2" (DN40 thru DN50)	1/2"-20	50-54 Ft-Lbs (67-73 N-m)

12. Reinstall adjusting screw (6) with jam nut (7).
13. Test for external leakage by spraying liquid leak detector around bolting (8) and body (1) and spring chamber (2) flanges. Ensure that an outlet pressure is maintained during this leak test of at least mid-range spring level; i.e. 10-40 psig (.69 - 2.8 Barg) range spring, 25 psig (1.7 Barg) test pressure minimum.

C. Trim Replacement:

1. Install body (1) in a vise with the body cap (5) on top and the body flange downwards.
NOTE: Do not secure by the adjusting screw (6) or jam nut (7).
2. Loosen and remove body cap (5).
3. Remove piston spring (17), piston (15), cylinder (16) and pusher plate (11). For Opt-20 the pusher plate cannot be removed from this position. Inspect parts for excessive wear, especially at seat surfaces. Replace if worn, nicked or depressed. (Valves equipped with Opt-4 Stabilizer will have the u-cup stabilizer seal (32) removed when the piston is removed from body (1). Remove stabilizer seal, if installed).
4. Remove the cylinder gasket (18) and clean contacting surface of body (1).
5. Clean flat mating surfaces of body (1) to body cap (5) shoulder.
6. Clean debris from within body (1) cavity. Clean parts to be reused.

NOTE: On regulators originally supplied as "oxygen clean", Option D-5, D-36, D-55, or DL-55, maintenance must include a level

of cleanliness equal to Cashco cleaning standard #S-1134. On regulators originally supplied as "cleaned for Pharmaceutical and Food applications", Option D-37 or D-37S, maintenance must include a level of cleanliness equal to Cashco cleaning standard #S-1576. Contact factory for details.

7. Reinstall the pusher plate (11). Ensure proper position of flat surface being downwards. Ensure centered.
8. Reinstall a new cylinder gasket (18). Press firmly and evenly into place using the cylinder (16). Do not use a "homemade" cylinder gasket.
9. Reinstall the cylinder (16) concentrically within the body cap (5) opening.
10. If supplied with Opt-4 Stabilizer, install new stabilizer seal (32) properly oriented onto piston (15). See Figure 1.
11. Slide the piston (15), including stabilizer seal (32) if supplied, slowly into place, assuring that the piston post slides into the female groove of the pusher plate (11). Use thumbs to ease stabilizer seal into cylinder (16).
12. Place piston spring (17) into piston (15) cavity.
13. Use pipe thread sealant applied to the body cap (5) threads. Thread body cap into body (1) as tight as possible by hand, then tighten to the following torque values.

For 3/8" & 1/2" size body cap - tighten cap to between 70 - 80 Ft-Lbs torque.
For 3/4" & 1" size body cap - tighten cap to between 125-150 Ft-Lbs.
14. Bench test unit for suitable operation. **NOTE:** Regulators are not tight shutoff devices. Even if pressure builds up beyond set point, a regulator may or may not develop bubble tight shutoff. In general, tighter shutoff can be expected with composition seat.
15. Spray liquid leak detector around body cap (5) and body (1) for test for leakage. Test pressure should be a minimum of 100 psig (6.9 Barg) at the inlet. Outlet should be tested to upper value of range spring (14).

NOTE: Comp seats are not removable from piston (15) assemblies. If composition seat is damaged, replace entire piston assembly.

SECTION VII

VII. TROUBLE SHOOTING GUIDE

1. Erratic operation; chattering.

Possible Causes	Remedies
A. Oversized regulator.	A1. Check actual flow conditions, resize regulator for minimum and maximum flow. A2. Decrease regulator pressure drop; decrease inlet pressure by placing a throttling orifice in inlet piping union; 2-stage pressure drop by using with another regulator in series. A3. Install next step higher range spring. Contact factory. A4. Before replacing regulator, contact factory.
B. Inadequate rangeability (regulator full capacity approximately 50% utilized).	B1. Decrease regulator pressure drop; decrease inlet pressure by placing a throttling orifice in inlet piping union; 2-stage pressure drop by using with another regulator in series. B2. Install next step higher range spring. Contact factory.
C. Worn piston/cylinder; inadequate guiding.	C. Replace trim.
D. Weakened/broken piston spring.	D. Replace piston spring. Determine if corrosion is causing the failure; if so, then consider alternate trims.
E. Flow induced instability.	E. Install Opt-4 Stabilizer on piston.

2. Downstream pressure will not reach desired setting.

Possible Causes	Remedies
A. Regulator undersized.	A1. Confirm by opening bypass valve together with regulator. A2. Check actual flow conditions, resize regulator; if regulator has inadequate capacity, replace with larger unit.
B. Plugged trim.	B. Remove trim and check for plugged holes in cylinder.
C. Incorrect range spring (screwing in CW of adjusting screw does not allow bringing pressure level up to proper level).	C. Replace range spring with proper higher range. Contact factory.
D. Too much proportional band (droop).	D1. Review P.B. (droop) expected. D2. Contact factory.
E. Restricted diaphragm movement.	E. Ensure no moisture in spring chamber at temperatures below freeze point. Ensure no dust or debris entering vent opening. If rainwater or debris can enter, re-orient spring chamber or install vent plug to the threaded vent hole.

3. Leakage through the spring chamber vent hole.

Possible Causes	Remedies
A. Normal-life diaphragm failure.	A. Replace diaphragm.
B. Abnormal short-life diaphragm failure.	B1. Can be caused by excessive chattering. See No. 1. to remedy chatter. B2. Can be caused by corrosive action. Consider alternate diaphragm material. B3. For composition diaphragms, ensure not subjecting to over-temperature conditions. B4. Downstream (outlet) pressure buildup occurring that overstresses diaphragms. Relocate regulator or protect with safety relief valve.

4. Excessive pressure downstream.

Possible Causes	Remedies
A. Regulator not closing tightly.	A. Inspect the seating. Clean and lap metal seat surfaces; replace if lapping does not remedy. If composition seats are depressed, nicked or embedded with debris, replace trim.
B. Downstream block.	B. Check system; isolate (block) flow at regulator inlet - not outlet. Relocate regulator if necessary..
C. No pressure relief protection.	C. Install safety relief valve, or rupture disc.
D. Restricted diaphragm movement.	D. Ensure no moisture in spring chamber at temperatures below freeze point. Ensure no dust or debris entering vent opening. If rainwater or debris can enter, re-orient spring chamber.

5. Sluggish operation.

Possible Causes	Remedies
A. Plugged spring chamber vent.	A. Clean vent opening.
B. Plugged piston balance port.	B. Remove trim and clean balance port.
C. Fluid too viscous.	C. Heat fluid. Contact factory.

SECTION VIII

VIII. ORDERING INFORMATION

NEW REPLACEMENT UNIT vs PARTS "KIT" FOR FIELD REPAIR

To obtain a quotation or place an order, please retrieve the Serial Number and Product Code that was etched on the metal name plate and attached to the unit. This information can also be found on the Bill of Material ("BOM"), a parts list that is available upon request. (Serial Number is a 13 digit number on the nameplate). Product Code typical format as follows: (last digit is alpha character that reflects revision level for the product).

□□□-□□□7-□□□□□□□□□□

NEW REPLACEMENT UNIT:

Contact your local Cashco Sales Representative with the Serial Number and Product code. With this information they can provide a quotation for a new unit including a complete description, price and availability.

PARTS "KIT" for FIELD REPAIR:

Contact your local Cashco Sales Representative with the Serial Number and Product code. Identify the parts and the quantity required to repair the unit from the cut sheet available on the following page.

NOTE: Those item numbers that have a quantity indicated under "Spare Parts" in column "A" reflect minimum parts required for inspection and rebuild, - "Soft Goods Kit". Those in column "B" include minimum trim replacement parts needed plus those "Soft Goods" parts from column "A".

A Local Sales Representative will provide quotation for appropriate Kit Number, Price and Availability.



CAUTION

Do not attempt to alter the original construction of any unit without assistance and approval from the factory. All purposed changes will require a new name plate with appropriate ratings and new product code to accommodate the recommended part(s) changes.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. We reserve the right to modify or improve the designs or specifications of such product at any time without notice. Cashco does not assume responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use and maintenance of any Cashco product remains solely with the purchaser.




Figure 1: Option-4 - Stabilizer




Figure 2: Basic Model D - Comp Diaphragm




Figure 3: Flow Arrow





Figure 4: Option-37 With Gauge




Figure 5: Option-20 - Dome Loaded

ITEM	GENERAL DESCRIPTION	SPARE PART	
		A	B
1	BODY		
2	SPRING CHAMBER		
3	PRESSURE PLATE		
4	SPRING BUTTON		
5	BODY CAP		
6	ADJUSTING SCREW		
7	HEX JAM NUT		
8	HEX HEAD CAP SCREW		
10	NAMEPLATE		
11	PUSHER PLATE		*
12	DIAPHRAGM	*	*
13	DIAPHRAGM GASKET	*	*
14	RANGE SPRING		
15	PISTON		*
15-1	PISTON		
15-2	SEAT DISC		
15-3	PUSHER POST		
16	CYLINDER		*
17	SPRING		*
18	CYLINDER GASKET	*	*
20	HANDWHEEL		
21	LOCKING LEVER		
25	LOCK WASHER, 3/8"		
26	GENERAL PURPOSE WASHER		
29	VENT PLUG		
30	SPRING PIN		
32	SEAL U-CUP (-018)	*	*
33	COVER DOME		
34	FLOW ARROW		
35	U-DRIVE SCREW		
40	NIPPLE		
41	FULL COUPLING		
42	GAUGE		
87	PIPE PLUG		

MODEL DL





Figure 6: Option D-3 or DL-3 Handwheel and Locking Lever

ITEM	GENERAL DESCRIPTION	SPARE PART	
		A	B
1	BODY		
2	SPRING CHAMBER		
3	PRESSURE PLATE		
4	SPRING BUTTON		
5	BODY CAP		
6	ADJUSTING SCREW		
7	HEX JAM NUT		
8	HEX HEAD CAP SCREW		
10	NAMEPLATE		
11	PUSHER PLATE		*
12	DIAPHRAGM	*	*
13	DIAPHRAGM GASKET	*	*
14	RANGE SPRING		
15	PISTON		*
15-1	PISTON		
15-2	SEAT DISC		
15-3	PUSHER POST		
16	CYLINDER		*
17	SPRING		*
18	CYLINDER GASKET	*	*
20	HANDWHEEL		
21	LOCKING LEVER		
25	LOCK WASHER, 3/8"		
26	GENERAL PURPOSE WASHER		
29	VENT PLUG		
30	SPRING PIN		
34	FLOW ARROW		
35	U-DRIVE SCREW		
87	PIPE PLUG		

ATEX 2014/34/EU: Explosive Atmospheres and Cashco Products



Cashco declares that the products listed in the table below has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of products intended for use in potentially explosive atmospheres given in Annex II of the ATEX Directive 2014/34/EU. Compliance with the Essential Health and Safety Requirements has been assured by compliance with EN ISO 80079-36:2016 and EN ISO 80079-37:2016. The product will be marked as follows:

CE Ex II 2 G
Ex h IIB T6... T1 Gb
1000ATEXR1 X

The 'X' placed after the technical file number indicates that the product is subject to specific conditions of use as follows:

1. The maximum surface temperature depends entirely on the operating conditions and not the equipment itself. The combination of the maximum ambient and the maximum process medium temperature shall be used to determine the maximum surface temperature and corresponding temperature classification, considering the safety margins described prescribed in EN ISO 80079-36:2016, Clause 8.2. Additionally, the system designer and users must take precautions to prevent rapid system pressurization which may raise the surface temperature of system components and tubing due to adiabatic compression of the system gas. Furthermore, the Joule-Thomson effect may cause process gases to rise in temperature as they expand going through a regulator. This could raise the external surface temperature of the regulator body and the downstream piping creating a potential source of ignition. Whether the Joule-Thomson effect leads to heating or cooling of the process gas depends on the process gas and the inlet and outlet pressures. The system designer is responsible for determining whether the process gas temperature may raise under any operating conditions.
2. Where the process medium is a liquid or semi-solid material with a surface resistance in excess of 1GΩ, special precautions shall be taken to ensure the process does not generate electrostatic discharge.
3. Special consideration shall be made regarding the filtration of the process medium if there is a potential for the process medium to contain solid particles. Where particles are present, the process flow shall be <1m/s (<3.3 ft/s) in order to prevent friction between the process medium and internal surfaces.
4. Effective earthing (grounding) of the product shall be ensured during installation.
5. The valve body/housing shall be regularly cleaned to prevent build up of dust deposits.
6. Regulators must be ordered with the non-relieving option (instead of the self-relieving option) if the process gas they are to be used with is hazardous (flammable, toxic, etc.). The self-relieving option vents process gas through the regulator cap directly into the atmosphere while the non-relieving option does not. Using regulators with the self-relieving option in a flammable gas system could create an explosive atmosphere in the vicinity of the regulator.
7. Tied diaphragm regulators with outlet ranges greater than 7 barg (100 psig) should be preset to minimize the risk that improper operation might lead to an outboard leak and a potentially explosive atmosphere.
8. All equipment must only be fitted with manufacturer's original spare parts.
9. Ensure that only non-sparking tools are used, as per EN 1127-1, Annex A.

	PRODUCT
REGULATORS	31-B, 31-N
	1164, 1164(OPT-45)
	1171, 1171(OPT-45), 1171(CRYO)
	2171, 2171(OPT-45), 2171(CRYO), 3171
	1465, 3381, 3381(OPT-45), 3381(OPT-40)
	4381, 4381(OPT-37), 4381(CRYO), 4381(OPT-45), 5381
	MPRV-H, MPRV-L
	PBE, PBE-L, PBE-H
	CA-1, CA-2
	CA1, SA1, CA4, SA4, CA5, SA5
	DA2, DA4, DA5, DA6, DA8
	DA0, DA1, DAP, SAP
	SLR-1, SLR-2, PTR-1
	ALR-1, ULR-1, PGR-1
	BQ, BQ(OPT-45), BQ(CRYO)
	123, 123(CRYO), 123(OPT-45), 123(OPT-46G)
	123-1+6, 123-1+6(OPT-45), 123-1+6(OPT-46G), 123-1+6+S, 123-1+6+S(OPT-40)
	1000HP, 1000HP(OPT-37), 1000HP(OPT-45), 1000HP(OPT-45G), 1000HP(CRYO)
	1000HP-1+6, 1000HP-1+8, 1000LP, 1000LP(OPT-45), 1000LP(OPT-46G)
	6987
	8310HP, 8310HP-1+6, 8310HP-1+8, 8310LP, 8311HP, 8311LP
	345, 345(OPT-45)
	BA1/BL1, PA1/PL1
	C-BPV, C-PRV, C-CS
	D, D(CRYO), D(OPT-37), D(OPT-20), D(OPT-45)
	DL, DL(LCC), DL(OPT-45)
	BR, BR(CRYO)
	HP, HP(LCC), HP(OPT-45), HP(OPT46G), HP-1+6+S(OPT-40), HP-1+6+S
	P1, P2, P3, P4, P5, P7
	B2, B7
	POSR-1, POSR-2
	5200P, 5300P
	135
	NW-PL, NW-SO
	CG-PILOT
	FG1
CONTROL VALVES	RANGER, 987, PREMIER
	964, 521, 988, 988-MB, 989
	2296/2296HF
	SCV-30, SCV-S
TANK BLANKETING	8700, 8910, 8920, 8930, 8940
	2100, 2199
	3100, 3200, 3300, 3400, 3500, 3600, 3700
	1078, 1088, 1100, 1049
	5100, 5200, 5400, 5500
	4100, 4200, 4300, 4400, 4500, 4600
MISC	764P/PD, 764-37, 764T

Cashco
P.O. Box 6
Ellsworth, KS 67439-0006
PH (785) 472-4461
Fax. # (785) 472-3539
www.cashco.com
email: sales@cashco.com
Printed in U.S.A. D/DL-IOM

Cashco GmbH
Handwerkerstrasse 15
15366 Hoppegarten, Germany
PH +49 3342 30968 0
Fax. No. +49 3342 30968 29
www.cashco.com
email: germany@cashco.com

Cashco do Brasil, Ltda.
Al.Venus, 340
Indaiatuba - Sao Paulo, Brazil
PH +55 11 99677 7177
Fax. No.
www.cashco.com
email: brazil@cashco.com